

OPERATING INSTRUCTIONS – DPT



ADJUST HEIGHT

- Hold [S] until numbers appear*
- Press/hold [v] or [^] to change height

CHECK CURRENT HEIGHT

Hold [S] and current height will appear on digital display

PROGRAM HEIGHTS

In one sequence:

- Hold [S] until numbers appear
- Press [v] or [^] to change to desired height
- Once at desired height press [S] then either [1], [2] or [3] to set

TO USE PROGRAMMED HEIGHTS

- Press [S] for numbers to appear
- Then hold either [1], [2] or [3] until desk gets to its programmed height

**Once numbers appear on screen (after holding [S]) you will only have a short amount of time to perform rest of the instructions for each task. If not done soon enough the numbers will disappear and you will have to hold [S] and start again.*

OPERATING INSTRUCTIONS – DPF1M



DPF1M

TO ADJUST THE TABLE HEIGHT

- Press and hold [v] or [^] to change the table height up or down

TO PROGRAM HEIGHTS

- Once you are at your preferred height press [S] and hold
- Press [1], [2] or [3] to set the height
- *Release all buttons and height is set*

TO USE PROGRAMMED HEIGHTS

- Hold either [1], [2] or [3] down constantly until the desk reaches its programmed height.